

Online Oxygen Purity Analyzer w/ Integral Sample System



The OMD-775 is designed to measure elevated oxygen levels (21% – 100%) for online applications. The unit combines an advanced set of electronic features with our industry leading precision electrochemical oxygen sensor technology. The analyzer also has built in temperature and barometric pressure compensation, the result is a highly reliable and cost effective design with an easy-to-use user interface.

The analyzer comes standard with a 0 – 100% full scale range with a resolution of 0.01%. The analyzer can also be configured by the end user in the field for suppressed ranges of 50 – 100%, 80 – 100% and 90 – 100%. The analyzer comes with the ability to auto-range through all four ranges, this is accomplished with the choice of a voltage or current analog output.

The analyzer offers the user 2 different digital communication options, both of which are bi-directional. These come in the form of MODBUS RS485 ASCII or RS232.

Alarm functionality is performed by 2 fully adjustable form C non-latching relay contacts. These can be configured as NO or NC and can be set as HIGH or LOW with optional delay mode. A power failure alarm is also standard and comes as a form C non-latching relay contact.

The oxygen sensor used in the OMD-775 is based on the galvanic electrochemical fuel cell principal and is compensated for both pressure and temperature giving the user added accuracy. All oxygen sensors are manufactured in house by Southland Sensing Ltd. under a strict quality program.

The analyzer is a cost-effective, yet similarly performing, alternative to paramagnetic oxygen sensors packaged in a 19" rack mount for easy installation and operation.

Applications:

- Air Liquefaction and Separation
- Gas Purity Certification
- Oxygen Monitoring of Medical Gases
- Ozone Generation PSA, VPSA
- Measurement in Wastewater Treatment Plants

0/50/80/90 - 100% Suppressed Ranges

Advanced Digital Temperature Compensation

Integral Barometric Pressure Compensation

Bi-Directional Communication Link

Extensive Electronic Features & Outputs

19" Rack Mount Configuration

Electrochemical Sensor Technology

Specifications

Accuracy:	< +/- 1% of Full Scale Range*
Alarms:	(2) Adjustable Relay Contacts (1) Power Fail Relay Contact
Analysis Range:	0/50/80/90 - 100%
Calibration:	Periodically
Communication:	Bi-Directional RS232 MODBUS RS485 ASCII
Dimensions:	19.0 x 5.125 x 7.75 inch
Display:	Large with Backlight
Enclosure:	Brushed Stainless Steel
Flow Sensitivity:	0.5 - 5 SCFH
Gas Connections:	1/8" Compression Tube
Output (Analog):	0 - 1V DC, 0 - 10V DC Isolated 4 - 20mA
Power:	100 - 240 VAC
Pressure:	Inlet, 0 - 50 PSIG
Range ID:	4 - 20 mA analog output 0 - 1 V DC analog output
Response Time:	T90 in 30 Seconds
Sample System:	Flow Control, 4-way sample / Flow Indicator
Sensor:	PO2-1120 Percent O2 Sensor
Sensor Life:	20 - 25 months @ 100% O2
Temperature:	0 - 50 deg C
Temperature Compensation:	Digital
Warranty:	12 months Analyzer & Sensor
Weight:	13.0 lbs

DASTEC S.R.L.

Representantes / Distribuidores Autorizados

Argentina

Tel: (+54 11) 5352 2500

Email: info@dastecsr.com.ar

Web: www.dastecsr.com.ar

Uruguay www.dastecsr.com.uy

Paraguay www.dastecsr.com.py