



Gas



Liquid & Slurry



Solid & Powder



Steam & Water

SENTRY SBC CONTROLLER

Sampler Controllers

AUTOMATIC SAMPLING

The Sentry® SBC controller is a dedicated logic control system capable of controlling any automatic sampler in the Sentry product line (liquid, slurry and bulk solids samplers). With just a few simple connections, the sampler can be in operation. The Quick Start screen guides you through the steps for setup.

The Sentry SBC controller features both Local and Remote operating modes.

MODEL

SBC

BENEFITS

Local mode allows the operator to obtain a single grab sample or to continuously sample. No other inputs are required.

The Sentry SBC controller offers a dry contact interface for remote starting and stopping of the sampler along with relay outputs for sampler running and alarm status. The Sentry SBC controller supports ModBus, CAN, Allen Bradley DF1, GE Fanuc SNP communications protocols without additional hardware.

The menu-driven interface allows quick and efficient access to all system parameters and information. The LCD screen provides constant information on the system status.

Customize operation by utilizing standard features, such as Batch sampling, Flow proportional sampling, Flow counter based sampling and control of the Sentry Indexing Cabinet (IC).

FEATURES

- Operator-friendly user interface
- Stand alone controller
- Remote operation controlled by a single contact
- Supports Modbus, CAN and other protocols
- Automatic continuous composite control
- Batch control
- Flow proportional control
- Integrates with remote mountable airset(s)
- Control of Sentry IC Indexing Cabinet, purchased separately

OPTIONS

- Stainless steel enclosure
- Gland plate
- Proximity sensor integration
- Ethernet interface
- Custom programming available
- Temperatures to -40°F (-40°C)



DASTEC S.R.L.

Representantes / Distribuidores Exclusivos

Buenos Aires, Argentina

Tel.: (54 - 11) 5352-2500

Email: info@dastecsrl.com.ar


Web: www.dastecsrl.com.ar




Sample. Monitor. Measure.

SENTRY

Any Application. Anywhere.



SPECIFICATIONS

| | |
|-----------------------------------|---|
| power | 100–240 VAC, 50/60 Hz, 1 phase, 1–7 A |
| inputs | digital: dry contacts, 24 VDC: remote enable, remote start; high-speed flow counter input, 200 µsec minimum pulse width inputs available for optional proximity sensors, 24 VDC analog: 4–20 mA, 10-bit resolution |
| outputs | mechanical relay, maximum 3 A at 250 VAC resistive |
| communications (option) | Modbus, CAN, Allen Bradley DF1, GE Fanuc SNP Ethernet (add'l hardware required) |
| keypad | 20 tactile feedback membrane switches |
| display | 128 x 64 pixel LCD display; graphics and text |
| enclosure | fiberglass; NEMA 4X, IP 65 |
| mounting | surface |
| ambient temperature | 32°F to 122°F (0°C to 50°C) |
| shipping weight (approx) | 17 lb (7.7 kg) |
| agency approvals available |  |

SOFTWARE FEATURES

| | |
|--------------------------|--|
| batch | user-defined number of samples taken |
| flow proportional | linear interpolation of sampling time based on 4–20 mA input |
| flow counter | sampling based on number of flow counter pulses |
| remote operation | sampling triggered by external input |
| delay start | event-based sampling with user-defined delay |
| indexing cabinet | integrated sampling and indexing cabinet control |

DASTEC S.R.L.

Representantes / Distribuidores Exclusivos
 Buenos Aires, Argentina
 Tel.: (54 - 11) 5352-2500
 Email: info@dastecsrl.com.ar
 Web: www.dastecsrl.com.ar

sentry-equip.com

966 Blue Ribbon Circle North, Oconomowoc, WI 53066 U.S.A. | +1-262-567-7256 | sales@sentry-equip.com

© 2016 Sentry Equipment Corp. All rights reserved. Sentry is a registered trademark of Sentry Equipment Corp. Modbus is a trademark of Schneider Electric USA. It is solely the responsibility of end users, through their own testing and analysis, to select products and materials suitable for their specific application requirements, ensure they are properly installed, safely applied and properly maintained, and to limit their use to their intended purpose. Improper selection, installation or use may result in personal injury or property damage.

S-LS-SPS-00181-4 12-16



COMPANY WITH
 QUALITY SYSTEM
 CERTIFIED BY DNV GL
 = ISO 9001 =